


PARTS DIAGRAM



Part List

PART NO.	DESCRIPTION	QTY
MK7-1-L	MK7 Main Body Left	1
MK7-1-R	MK7 Main Body Right	1
MK7-3	Bottom Cover (optional)	1
MK7-4	Hook (optional)	1
MK7-5	Magazine Feed Cover	1
Mk7-6	Magazine Housing	1
MK7-7	Ball Stopper	1
MK7-8	Nut	5
MK7-9	Screw-1	1
MK7-10	Magazine Housing Pin	1
MK7-11	Magazine Hook	1
MK7-12	Magazine Release	1
MK7-13	Air Plug	2
MK7-14	O-Ring	1
MK7-15	Magazine Set Nut	1
MK7-16	Magazine Set Screw	1
MK7-17	Magazine Spring	1

Installation Information:

1. Verify that all the parts and the designated quantities are supplied in accordance to the part list table
2. Use your manufacture user manual as reference to disassemble and reassemble of the new parts provided
3. Additional installation guide and step by step installation videos are available at tacamopaintball.com/support/