





02-13
Cocking
Handle

TA07074
Receiver
Bolt (Long)

TA10016
Rear Sight

PL-42A
Screw

T210007
Hopper
Complete

02-PIN
Pin (Short)

02-48
Washer

02-PIN
Pin (Short)

TA10007
Front Sight

TA10031
Receiver
Left

TA07065
Sight Bolt

TA07065
Sight Bolt

98-01A
Receiver
Bolt (Short)

TP03114
Nameplate

TA10023
Screw (2)

TA10002
Accessory
Rail

98-01A
Receiver
Bolt (Short)

02-39
Barrel

CA-02A
Bolt BHCS (2)

TA10023
Screw (2)

02-41
Feeder
Housing Bolt

TA10045
Push Pin
Long

TA10005
Front Grip
Left

TA10045
Push Pin
Long

TA10021
Trigger

TA10020
Safety

PL-42A
Screw (3)

02-38
Trigger
Guard

TA10010
Lower Receiver
Left

TA10013
Magazine Base

TA10015
Magazine Pin

TA10024
Gas Line

98-01B
Receiver
Bolt Long

TA10012
Magazine

TA10025
Gas Line
Elbow

02-06
Tank Adapter



02-69
Barrel
Adapter

TA01008
Barrel Adapter
Oring

02-13
Cocking
Handle

02-14
Cocking Handle
Spring

98-16
Linkage Arm

TA01010
Rear Bolt
Plug

FA-18
Ball Latch

02-17
Front Bolt

TA10030
Receiver
Right

TA10022
Tombstone
Adapter

Power
Tube

98-12A
Rear Bolt
O-ring

02-11
Rear Bolt

CA-14
Drive Spring

CA-15
Guide Pin

02-58
O-ring
Retainer

TA10050
End Cap

98-57
Buffer O-ring

4-PA
Sling Swivel

TA10057
End Cap
Bushing




TA10015
Magazine Pin

02-20S
Magazine Spring
Red (2)

TA10013
Magazine Base

TA10014
Magazine
Button



02-20S
Spring
(Red)

02-33
Trigger Plate
Pin (4)

02-33A
Sear Pin
(Black)

02-35
Sear

02-20
Sear Spring
(Blue)


98-18
Slider


98-19
Slider Pin (2)

02-20
Slider Spring
Blue, not visible

02-67R
Right Trigger
Plate

TA10021
Trigger





02-33A
Sear Pin
(Black)

02-33
Trigger Plate
Pin (4)

02-20S
Spring
(Red)

02-67R
Right Trigger Plate

TA10010
Lower
Receiver Left

02-38
Trigger
Guard

TA10021
Trigger

02-06
Tank Adapter

TA10025
Gas Line
Elbow

